

- -- Contains its own ink
- -- Prints in two colours
- -- Perfect impressions assured
- →No pad required





POROUS RUBBER STAMPS

NPR (No Pad Required) EASISTAMP

THE STAMP FOR WHICH EVERY TRADE AND BUSINESS HAS A USE. A PRODUCT OF THE NCR RESEARCH & DEVELOPMENT LABORATORIES

FEATURES

Wood handle enamelled red Nickel plated compression ring Nickel plated shield and guide Aluminium holder containing die Porous rubber die

ADVANTAGES

Always ready for use

NO STAMP PAD REQUIRED. The porous rubber die is of Micro Cellular construction embodying a built-in ink reservoir.

EASY TO USE

Stand the NPR EASISTAMP where the impression is required. Press handle gently and firmly. As the stamp is fully inked, **no force is required.** The Shield or Guide holds the inked die off the paper so that the stamp can be positioned without marking the paper until the handle is depressed.

The depth of the Die Holder is arranged to form a stop, so that when full pressure is applied a perfect impression is assured. When pressure is released the Compression Spring returns the inked die within the protecting Shield.

PENCIL END STAMPS

MODEL P.E Modern business can find many uses for a rubber stamp attached to the end of a pencil such as Identification, Approval, Receiving, Checking, Authorisation, and other purposes. A retractable shell protects the stamp and also prevents ink from touching hands and clothing. MODEL D.U. An alternative design fitted with small wood handle, suitable for desk use.

SIGNATURE STAMPS

The de luxe model Signature Stamp is of modern construction and design and is eminently suitable for Executive use. The porous rubber is attached to the black plastic handle, which when not in use rests in the small flat base.

INKS FOR POROUS RUBBER STAMPS

Standard stamps, signature stamps and pencil stamps are impregnated at one stage of the Manufacturing Process with **purple**, **red or blue** ink according to customer choice and once inked the colour cannot be changed. Stamps inked black can however be supplied against specific demands.

If no colour is indicated, purple will be supplied.

For the convenience of refreshing NPR easistamp special refresher ink is supplied in $\frac{1}{2}$ oz and 1 oz bottles.

To refresh your NPR EASISTAMP make sure the printing surface is clean and free from dust or paper lint. Apply ink liberally to upturned surface of stamp using brush mounted in bottle cap and leave overnight. Before re-use remove any unabsorbed ink by taking one or two impressions on blotting paper. Repeat as necessary for complete charging.









a.h.Other

IMPORTANT. Use only NPR EASISTAMP Inks. Other inks will injure the porous rubber and render the stamp useless.

Whilst NPR Easistamps will give several thousand impressions before the need to re-ink arises, due to the slow flowing nature of the ink itself it is necessary to rest the stamp temporarily between batches of say 30 impressions at one time and this point should be borne in mind where continuous repetitive stampings are required.

P & S 19